


With correct setting up diffs will
run more quietly & last longer
- you just need the right tools.



How to get the perfect contact pattern:


- * Apply Gear Marking Compound to the teeth of the crownwheel with a brush.
- * Rotate the crownwheel & pinion clockwise then counter clockwise.
- * Carefully note the contact pattern where the Gear Marking Compound has been wiped off by the action of the pinion against the crown-wheel.
- * An ideal contact pattern is one located on the centre of the tooth surface.



Diff Lapping Gear Marking Compound

- * Easy to apply - easy to remove.
- * Shows the contact pattern clearly.
- * Our handy pocket-sized tin will cover all your marking needs - a little goes a long way.
- * Suitable for use on any type of diff gearset.

LET US HELP YOU WITH THE PERFECT DIFF SET-UP!



Got a hum in the bum? Had a biff in the diff?

DIFF LAPPING & REPAIRS

We'll keep your rear end quiet!

www.difflap.com.au

**Call us now
07 3359 4701**